



## **XYLOPHONE Outdoor Collection**

Shown Above MO0610 Xylophone Arm Chair MO0672 Table/Stool



MO0615 Xylophone Bench



MO0611 Xylophone Two Seater Bench





MO0610 Xylophone Arm Chair MO0670 Extension Table





XYLOPHONE Chaise Lounge

MO0612 Xylophone Chaise Lounge

MO0600 Cushion Set

## Hightower Group LLC

New York Design Center – 200 Lexington Avenue – Studio 1316 – New York, NY 10016

(P) 212.725.3509 (E) service@hightoweraccess.com

### Xylophone Outdoor Collection

		<b>LIST</b>
<b>MO0615</b>	<b>Xylophone Bench. Teak Slats. Galvanized Steel. W 23 1/2 L 56 1/4 W 15 3/4 H 15 3/4</b>	<b>1995</b>
MO0609	Xylophone Armless Dining Chair. Teak Slats. Galvanized Steel. W 18 1/2 D 18 1/4 H 29 1/2 SH 15 3/4	1275
MO0610	Xylophone Arm Chair. Teak Slats. Galvanized Steel. W 23 1/4 D 24 3/4 H 29 1/2 SH 15 3/4	1445
MO0611	Xylophone 2 Seater Armed Bench. Teak Slats. Galvanized Steel. W 46 1/2 D 24 3/4 H 29 1/2 SH 15 3/4	2795
MO0672	Xylophone Stool/Table. Teak Slats. Galvanized Steel. W 17 1/2 D 19 3/4 H 29 1/2 SH 15 3/4	995
MO0612	Xylophone Chaise Lounge. Teak Slats. Galvanized Steel. W 23 1/2 L 76 1/4 H 15 3/4	3795
MO6600X	Cushion for MO0610 Chair	395
MO6700X	Cushion for MO0612 Chaise	695
MO0673	Xylophone Square Dining Table. Teak Slats. Galvanized Steel. W 31 1/2 D 31 1/2 H 27 1/2	1795
MO0675	Xylophone Square Dining Table. Teak Slats. Galvanized Steel. W 47 1/4 D 47 1/4 H 27 1/2	2950
MO0665	Xylophone Extension Table. Teak Slats. Galvanized Steel. L 57 (Closed) 99 1/4 (Open) W 33 1/2 H 26	3995
MO0670	Xylophone Extension Table. Teak Slats. Galvanized Steel. L 57 (Closed) 99 1/4 (Open) W 27 1/2 H 26	3925