

HighTower

Berliner



Model #S-3911

Berliner Lounge Chair W 29 ½ D 27 ½ H 25 ½ SH 17 COM (4 yds)

Chrome legs Hightower Ecosoft Leather (42 Colors) No COL.

COM	Leather	3	4	5	6	7	8	9	10
2795	3850	2959	2883	2907	3027	3171	3283	3407	3675
11	12	13							
3815	3995	4016							

HighTower

Berliner



Model #S-3918

Berliner Sofa W 70 ¾ D 27 ½ H 25 ½ SH 17 COM (7 yds)

Chrome legs standard. Hightower Ecosoft Leather (42 Colors) No COL.

COM	Leather	3	4	5	6	7	8	9	10
5595	6975	5882	5999	6216	6380	6578	6774	6891	7285

HighTower

Berliner



Berliner sofa shown with Flower table



Berliner sofa and chairs shown with Brasilia table