



Model #SKA-F-288

Boxer Lounge Chair    W 30 ½ D 31 ¼ H 28 ½ SH 15 ¼    COM ( 3 yds )

Chrome base.    Hightower Ecosoft Leather (42 Colors)    No COL.

COM	Leather	3	4	5	6	7	8	9	10
2350	3595	2473	2566	2659	2749	2857	2941	3034	3160
11	12	13	14	15	16	17	18	19	
3340	3400	3491	3582	3673	3763	3856	4042	4135	



Model #SKA-S-290

Boxer Sofa    W 68 ¼ D 31 ¼ H 28 ½ SH 15 ¼    COM ( 6 ¼ yds )

Chrome base.    Hightower Ecosoft Leather (42 Colors)    No COL.

COM	Leather	3	4	5	6	7	8	9	10
4750	7195	5006	5200	5394	5581	5806	5981	6175	6438
11	12	13	14	15	16	17	18	19	
6813	6938	7127	7317	7506	7693	7887	8275	8468	

HighTower

Boxer



HighTower Group • 200 Lexington Avenue • Studio 1316 • New York, NY 10016

(P) 212.725.3509 (E) [service@hightoweraccess.com](mailto:service@hightoweraccess.com)