



MO8511 Parade Guest Chair. Wood Back. Upholstered Seat. COM (1/2 yd)
 Maple Back & Seat Edge. Clear Lacquered or Optional Black Finish.
 W 20 1/2 D 20 H 33 SH 17 3/4

COM	Leather	3	4	5	6	7	8	9	10
795	925	816	831	847	862	880	894	909	930

Hightower Ecosoft Leather (42 Colors) No COL.
 Mirror Chrome Legs Standard. Option: Brush Satin Chrome Frame +75 LIST



MO8513 Parade Guest Arm Chair. Wood Back. Upholstered Seat. COM (1/2 yd)
 Maple Back & Seat Edge. Clear Lacquered or Optional Black Finish.
 W 23 D 20 H 33 SH 17 ¾

COM	Leather	3	4	5	6	7	8	9	10
925	1060	946	961	977	992	1010	1024	1039	1060

Hightower Ecosoft Leather (42 Colors) No COL.
 Mirror Chrome Legs Standard. Option: Brush Satin Chrome Frame +75 LIST

HighTower

Pablo Stacker



HighTower Group • 200 Lexington Avenue • Studio 1316 • New York, NY 10016
(P) 212.725.3509 (E) service@hightoweraccess.com