



XYLOPHONE Outdoor Collection

Shown Above M00610 Xylophone Arm Chair M00672 Table/Stool



MO0615 Xylophone Bench



MO0611 Xylophone Two Seater Bench





MO0610 Xylophone Arm Chair MO0670 Extension Table





XYLOPHONE Chaise Lounge

M00612 Xylophone Chaise Lounge

M00600 Cushion Set

Hightower Group LLC

New York Design Center – 200 Lexington Avenue – Studio 1316 – New York, NY 10016

(P) 212.725.3509 (E) service@hightoweraccess.com

Xylophone Outdoor Collection

		LIST
MO0615	Xylophone Bench. Teak Slats. Galvanized W 23 1/2 L 56 1/4 W 15 3/4 H 15 3/4	2295
MO0609	Xylophone Armless Dining Chair. Teak Slats. Galvanized Steel. W 18 1/2 D 18 1/4 H 29 1/2 SH 15 3/4	1575
MO0610	Xylophone Arm Chair. Teak Slats. Galvanized Steel. W 23 1/4 D 24 3/4 H 29 1/2 SH 15 3/4	1745
MO0611	Xylophone 2 Seater Armed Bench. Teak Slats. Galvanized Steel. W 46 1/2 D 24 3/4 H 29 1/2 SH 15 3/4	3295
MO0672	Xylophone Stool/Table. Teak Slats. Galvanized Steel. W 17 1/2 D 19 3/4 H 29 1/2 SH 15 3/4	1195
MO0612	Xylophone Chaise Lounge. Teak Slats. Galvanized Steel. W 23 1/2 L 76 1/4 H 15 3/4	3995
MO6600X	Cushion for MO0610 Chair	395
MO6700X	Cushion for MO0612 Chaise	695
MO0673	Xylophone Square Dining Table. Teak Slats. Galvanized Steel. W 31 1/2 D 31 1/2 H 27 1/2	2195
MO0675	Xylophone Square Dining Table. Teak Slats. Galvanized Steel. W 47 1/4 D 47 1/4 H 27 1/2	3350
MO0665	Xylophone Extension Table. Teak Slats. Galvanized Steel. L 57 (Closed) 99 1/4 (Open) W 33 1/2 H 26	4295
MO0670	Xylophone Extension Table. Teak Slats. Galvanized Steel. L 57 (Closed) 99 1/4 (Open) W 27 1/2 H 26	4625